



Secure vases, picture frames, and other small items

Why

- Prevents fragile or valuable items from falling, breaking, or becoming projectiles during an earthquake.

How

- Protect loose items in cabinets or other storage with locks to ensure doors remain shut during an earthquake. For items that remain on surfaces, use adhesives specially designed to anchor vases, picture frames, collectibles, and other small items to shelves and surfaces during an earthquake.

How to Identify

- Check shelves, mantels, and countertops for unsecured items that could shift or fall. Focus on breakables or anything stored overhead.
- Complete a home earthquake safety list or consult with a seismic safety professional who can help spot risks and identify solutions.